


PARTS LIST

for



AUTOMATIC WASHER

MODEL
RAB4132AW0
▲

▲W-White, L-Almond,
G-Golden Harvest




FOR CUSTOMER SATISFACTION ALWAYS USE
FACTORY SPECIFICATION PARTS



Whirlpool CORPORATION
Benton Harbor, Michigan.

TOP AND CABINET PARTS

For Model: RAB4132AW0



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CABINET PARTS

For Model: RAB4132AW0

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	357213	Nut, Push-In (2)	8	3356311	Screw & Washer,	19		Lid
2		Top			Lid Switch (2)		3351652	White
	3358226	White	11	3352631	Switch, Lid		3351653	Almond
	3358227	Almond	13	3351355	Screw, Lid Hinge		3351656	Golden Harvest
	3358228	Golden Harvest			Mounting (4)	20	358684	Strike, Lid Switch
3	62750	Spacer, Cabinet To	14	21097	Pad, Lid Hinge (2)	21	63289	Dispenser,
		Top (4)	15	54584	Hinge, Lid (L.H.)			Bleach
5		Cabinet	16	54583	Hinge, Lid (R.H.)	22	93770	Bumper, Lid (2)
	63128	White	17	19119	Bumper, Lid Hinge	28	384435	Screw,
	63129	Almond	18	21258	Bearing, Lid			10-16 x 1/2 (4)
	63132	Golden Harvest			Hinge (2)	30	354239	Rivet, Serial
6	62780	Clip, Top & Cabinet						Nameplate
		& Rear Panel (2)				31	90016	Clip, Harness


LITERATURE AND OPTIONAL PARTS

Illus. Part No. No. DESCRIPTION	Illus. Part No. No. DESCRIPTION	Illus. Part No. No. DESCRIPTION
<u>LITERATURE PARTS</u>	<u>OPTIONAL PARTS NOT INCLUDED</u>	
LIT3358964 Sheet, Installation Instructions	<u>PAINT, TOUCH-UP (1/2oz.)</u>	<u>OIL</u>
LIT3357462 Guide, Use and Care	72017 White	350572 Oil, Gearcase (16 Oz.)
LIT3358676 Energy Guide	72107 Almond	
LIT881007 List, Repair Parts	72110 Golden Harvest	<u>LUBRICANT</u>
LIT3351736 Label, Wiring Diagram	<u>PAINT, PRESSURIZED SPRAY (13 oz.)</u>	285208 Lubricant (Use Only in Brake Shoe Assembly On Roller and Pin)
	350941 Leveler (Thinner)	<u>SEALER</u>
	350938 Primer, Gray	285195 Sealer, Gasket (.20 Fl. Oz.) (6 ml)
	350930 White	<u>SHIPPING KIT</u>
	350956 Almond	3348675 Shipping Kit
	261890 Golden Harvest	<u>ACCESSORY PARTS</u>
	<u>PAINT, BULK (1 qt.)</u>	3359794 Fabric Dispenser
	799344 White (Uncut)	367031 Drain Protector
	978883 Almond (Uncut)	89121 Stand-Pipe Kit
	261891 Golden Harvest (Uncut)	285320 Siphon Break Kit

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROLS AND REAR PANEL PARTS

For Model: RAB4132AW0





FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL AND REAR PANEL PARTS


For Model: RAB4132AW0

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	16123	Washer, Water Inlet Hose (4) (1-1/16 x 5/8)	14	62734	Cord, Power	31	660628	Clamp, Hose 272858 (Alt.) 353097 (Alt.)
2	661538	Switch, Water Temperature	15	63848	Strain Relief, Power Cord	32	62731	Hose, Pump To Tub
3	660028	Hose, Water Inlet (2) 81339 (Alt.) 366108 (Alt.) 385057 (Alt.)	16	3358016	Cap, End (L.H.)	36	96435	Screw, Timer Mounting (10-32 x 1) (2)
5	387402	Hinge, Console (2)	17	96160	Screen, Filter (2)	37	3352167	Knob, Control
6	3357976	Panel, Rear	18	358992	Valve, Water Mixing	39	3359598	Panel, Console
7	62747	Pad, Rear Panel	19	90864	Screw, 10-24 x 3/8 (2)	40	689559	Nut, Push-In (2)
8	661575	Hose, Drain (5-1/2 Ft.)	21	660632	Clamp, Hose 272846 (Alt.) 353367 (Alt.)	44	3352173	Knob, Timer
	661577	Hose, Drain (10 Ft.) (Not Included)	22	62662	Hose, Vacuum Break	45	3388184	Dial, Timer
9	3351734	Timer, Control (60 Hz.) (Motor Not A Service Part)	23	371503	Clamp, Hose	49	64211	Screw, 8-18 (2) (Panel to Top)
11	3390646	Screw, 8-18 x 5/16	24	3347034	Break, Vacuum	50	62863	Screw, 10-16 x 3/8
12	3356468	Switch, Water Level	25	63290	Support, Rear Panel	51	3357998	Cap, End (R.H.)
13	3358895	Bracket, Control	26	3355497	Connector, Drain Hose	55	3357011	Screw, 10-16 x 1/2
			27	356138	Clamp, Hose	56	3357331	Clamp, Drain Hose
			28	3359818	Hose, Pump To Drain Connector			
			30	371502	Clamp, Hose 370447 (Alt.)			

WATER SYSTEM PARTS



Illus. No.	Part No.	DESCRIPTION
1	285442	Connector Kit, Plastic Drain Hose
2	285321	Sleeve Kit, (Contains 2 Sleeves)
3	370447	Clamp, Hose
4	16272	Connector, Straight
5	285320	Siphon Break Kit (Not Included)
6	65349	Clamp, Hose
7	367031	Drain Protector (Not Included)




WS400

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

AGITATOR, BASKET AND TUB PARTS

For Model: RAB4132AW0




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

AGITATOR, BASKET AND TUB PARTS

For Model: RAB4132AW0

Illus. No.	Part No.	DESCRIPTION
1	3355761	Cap, Agitator
2	358237	Screw & Washer (5-16-24 x 1)
3	3352284	Snap-In-Plugs (4)
4	3352103	Agitator
5	387966	Tub Ring & Gasket
6	63222	Gasket, Tub Ring
7	387868	Balance Ring
8	387867	Clip, Balance Ring (8)
9	3352105	Filter, Manual
10	63323	Hose, Bleach
11	356436	Clamp, Hose
12	21366	Nut, Spanner
13	387713	Basket
16	63039	Tub
17	389140	Block, Basket Drive
18	383727	Gasket, Centerpost
19	386757	Hose, Pressure Switch

MISCELLANEOUS PARTS




Illus. No.	Part No.	DESCRIPTION
1	3356711	Miscellaneous Parts Bag
2	16123	Washer, Inlet Hose (1-1/16 x 5/8) (4)
4	62739	Nut, Lock (2) (3/8-16)
5	389102	Foot, Front (2)
7	356138	Clamp, Hose

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


BRAKE, CLUTCH, GEARCASE, MOTOR AND PUMP PARTS

For Model: RAB4132AW0



Illus. No.	Part No.	DESCRIPTION
1	388951	Brake & Drive Tube (Complete) (Refer to Page 11 For Further Breakdown)
2	63292	Washer, Spin Tube Thrust
3	62697	Ring, Spin Tube Support
4	63283	Ring, Retainer
5	3350115	Clutch (Complete)
6	388190	Band & Lining, Clutch (Includes Illus. 7 & 8)
7	62646	Cap, Clutch Spring (2)
8	3354731	Spring, Clutch
9	389246	Gearcase (Complete) (Refer To Page 12 For Further Breakdown)
10	62735	Screw, Gearcase To Base (3) (5/16-24 x 3/4)
11	62611	Plate, Motor Mount To Gearcase


Illus. No.	Part No.	DESCRIPTION
12	62691	Grommet, Motor (4)
13	661560	Coupling, Motor And Isolation (2)
14	3387485	Screw (2) #10-16 x 5/8
15	3351341	Shield, Motor
16	98062	Screw, 5/16-24 x 5/8 (2)
17	3349637	Retainer, Motor (2)
18	3349282	Shield, Tub To Motor
19	3349643	Motor, Main Drive
20	62851	Switch, Main Drive Motor
21	62700	Retainer, Pump (2)
22	3352492	Pump (Complete)
23	3355454	Clip, Anti-Rattle
24	9420601	Screw, 10-16 x 5/16
25	357030	Clamp, Capacitor
26	357021	Capacitor, Start



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MACHINE BASE PARTS

For Model: RAB4132AW0




Illus. No.	Part No.	DESCRIPTION
1	98610	Screw, Bracket Mounting (10-16 x 5/8) (6)
2	64067	Bracket, Spring Outer (2)
3	63907	Spring Suspension (3)
4	389350	Support & Brake, Tub
5	64065	Bracket, Spring Outer (L.F.)
6	3348725	Link, Leveling Mechanism (2)
7	62597	Spring, Leveling Mechanism
8	62837	Pin, Knurled
9	62596	Foot, Rear (2)
13	3347047	Bearing, Centerpost (2)
14	357409	Seal, Centerpost (3)
15	388492	Spring, Counterweight
16	62568	Pad, Plate
17	389299	Plate, Suspension (Includes Illus. 16)
18	62602	Pad, Base
19	3349337	Base Assembly (Includes Illus. 6, 7, 8, 9, 18 & 26)
21	62739	Nut, Lock (3/8-16) (2)
22	389102	Foot, Front (2)
23	356934	Seal, Centerpost (2)
24	285203	Centerpost Bearing Kit (Includes Illus. 13, 14 & 23)
25	63134	Ring, Sound Deadening
26	63806	Retainer, Suspension Spring

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

WIRING HARNESS PARTS


For Model: RAB4132AW0

RETAINER CLIPS



Illus. No.	Part No.	DESCRIPTION
1	3349557	Clip, Harness
2	62749	Clip, Harness
3	98997	Clip, Harness
4	3352501	Clip, Harness (3)
5	90016	Clip, Harness
6	3390496	Clip, Harness
7	3359860	Wiring Harness & Pressure Switch Hose
9	3369366	Block, Disconnect (Black) (Timer)
10	3354924	Terminal, Female
11	62889	Receptacle, Terminal (3-Way) (Lid Switch)
12	94614	Terminal, Female
13	353424	Plug, Terminal (3-Way) (Power Cord)
14	94613	Terminal, Male
15	62505	Block, Disconnect (Motor)
16	386757	Hose, Pressure Switch
17	3347243	Connector, Temp. Switch
18	63523	Protector, Harness
19	3371761	Terminal


WIRING HARNESS



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BRAKE AND DRIVE TUBE PARTS

For Model: RAB4132AW0



Illus. No.	Part No.	DESCRIPTION
1	388951	Brake And Drive Tube (Complete)
2	62658	Ring, Thrust
3	91939	Seal, Oil
4	356427	Seal, Drive Tube
5	356937	Spacer, Drive Tube
6	64027	Tube, Basket Drive (Includes Illus. 3, 4, 5 & 9)
7	64035	Ring, Retaining
8	64232	Brake Shoe
9	62703	"T" Bearing, Spin Tube
10	62648	Cap, Brake Spring (2)
11	62647	Spring, Brake
12	62909	Sleeve, Brake Spring
13	63023	Cam, Brake Release
14	63022	Sleeve, Cam
15	64194	Driver, Brake Cam
16	90368	Ring, Retaining


FOLLOWING PARTS NOT ILLUSTRATED

285208 Lubricant
(Use Only In
Brake Shoe
Assembly On
Roller & Pin)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

GEARCASE PARTS

For Model: RAB4132AW0



Illus. No.	Part No.	DESCRIPTION
1	389246	Gearcase (Complete)
2	62685	Cover, Gearcase
3	3347188	Seal, Gearcase Cover
4	285195	Sealer, Gasket (.20 Fl. Oz.) (6 ml)
5	63320	Pinion, Spin (Includes Illus. 25)
6	356427	Seal, Spin Pinion
7	389387	Shaft, Agitator (Complete)
8	90369	Ring, Retaining (2)
9	62677	Retainer, Spring (2)
10	62676	Spring, Agitate
11	63273	Gear, Agitator
12	62619	Washer, Agitator Gear
13	62580	Follower, Cam
14	62581	Cam, Agitator
15	389231	Shaft, Agitator
16	62618	Washer, Cam Thrust
17	16018	Bearing, Thrust
18	85529	Ball, Bearing
19	389229	Bottom and Pinion, Gearcase
20	62528	Gear, Main Drive
21	285352	Seal, Thrust Plug
22	90864	Screw, Gearcase Cover Mounting (8)
23	95082	Ring, Retaining
24	285292	Washer Kit, Thrust
25	62570	Gear, Spin
26	388253	Neutral Assembly
27	62534	Rack, Connecting
28	62621	Actuator, Shift
29	388815	Washer, Intermediate

GC212A

GC212A

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST